

<p>4. Wartung Einschraubfilter mit Blende am Eingang 12 (x) entfernen und mit Brennspritus oder Freon TF reinigen und ausblasen. Gehäuse und Frontscheibe nur mit Brennspritus oder Freon TF reinigen</p> <p>Achtung: Der Zeiter fällt nicht unter die ATEX-Richtlinien.</p> <p>Bei Einsatz in ATEX-relevanter Umgebung ist jedoch darauf zu achten, dass es auf der Gehäuseoberfläche nicht zu einer statischen Aufladung kommen kann.</p> <p>Somit nur mit einem feuchten Tuch reinigen.</p>	<p>3.6. Port no. 4 is plugged to provide the user with a – valve function. Removal of the plug from port no. 4 will facilitate full $\frac{5}{2}$ - valve function.</p> <p>4. Service tips Remove screw-type filter at port 12 (x) and clean with either methylated spirit or freon TF using a compressed air gun. The housing and front plate must only be cleaned with either methylated spirit or freon TF.</p> <p>Attention: The timer comes not under the ATEX-regulations.</p> <p>By using it within ATEX-relevant environment it has to be taken care, that the case surface does not become an electrostatic charge.</p> <p>So wipe (only) with a damp cloth.</p>	
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

WIR BRINGEN BEWEGUNG IN BESONDERE UMGEBUNGEN.

